




Installation manual

ROTEX HPSU Bi-Bloc Ultra











RHBX04DA6V
RHBX04DA9W
RHBX08DA6V
RHBX08DA9W

Installation manual
ROTEX HPSU Bi-Bloc Ultra

English

CE - DECLARATION OF CONFORMITY
CE - KONFORMITÄTSERKLÄRUNG
CE - DICHLARAZIONE DI CONFORMITÀ
CE - ΔΗΛΩΣΗ ΣΥΜΠΟΡΦΩΣΗΣ
CE - DECLARACION DE CONFORMIDAD
CE - DICHLARAZIONE DI CONFORMITÀ
CE - ДИЧЛАРАЦІЯ СООТВѢТСТВИЯ
CE - DECLARATION DE CONFORMITE
CE - KONFORMITÄTSERKLÄRUNG

ROTEX

01  déclare under its sole responsibility that the equipment to which this declaration relates:
02  erklärt auf seine alleinige Verantwortung, dass die Ausrüstung für diese Erklärung bestimmt ist:
03  déclare sous sa seule responsabilité que l'équipement visé par la présente déclaration:
04  verklaart hierbij op zijn eigen oorspronkelijke verantwoordelijkheid dat de apparatuur waarop deze verklaring betrekking heeft:
05  declara bajo su propia responsabilidad que el equipo al que hace referencia la declaración:
06  δηλώνει υπό την αποκλειστική του ευθύνη ότι η παρούσα δήλωση αφορά:
07  обьявляю на основании лишь собственного опыта и ответственности, что данное оборудование:
08  declara sob sua exclusiva responsabilidade que os equipamentos a que esta declaração se refere:

RHBX04DA6V, RHBX04DA9W, RHBX08DA6V, RHBX08DA9W,

01 are in conformity with the following standard(s) or other normative document(s), provided that these are used in accordance with our instructions:
02 deriven (følgende Normen) eller enen anden Normdokument eller Dokumenten enskriftensispejlspejlen, under det Forudsætning, at de gennås
03 unserer Anweisungen eingehalten werden:
04 sont conformes à l(au)x norm(e) (ou autre(s) document(s) normatif(s), pour autant qu'il/s soient utilisés conformément à nos instructions:
05 conform de valgete norm(e) (d'én d' meer andere bindende documenten zijn op voorwaarde dat ze worden gebruikt overeenkomstig onze
instruksies:
06 están en conformidad con la(s) siguiente(s) norma(s) u otro(s) documento(s) normativo(s), siempre que sean utilizados de acuerdo con nuestras
instrucciones:
07 sono conformi all(elle) standard(s) o altro(i) document(i) a carattere normativo, a patto che vengano usati in conformità alle nostre istruzioni:
08 ενα σύμφωνα με το(α) κανονισ(α) ή(α) έγγραφο(α) πρότυπο(α) ή(α) άλλο έγγραφο(α) κανονιστικό, υπό την προϋπόθεση ότι χρησιμοποιούνται
σύμφωνα με τις οδηγίες μας:

EN60335-2-40,

01 following the provisions of:
02 gemäß den Vorschriften der:
03 conformément aux stipulations des:
04 overeenkomstig de bepalingen van:
05 σύμφωνα με διατάξεις των:
06 secondo le prescrizioni per:
07 на основании положений тур:
08 de acordo com o preito etc:
09 в соответствии с положениями:
10 under l(au)gtagelse af bestemmelserne i:
11 enligt villkoren i:
12 gitt i henhold til bestemmelserne i:
13 noudatiiden määräyksiä:
14 za dodržení ustanovení předpisů:
15 prema odredbama:
16 követi azt:
17 zgodnie z postanowieniami Dyrektywy:
18 in una preveditor.









01 **Note** as set out in <A> and judged positively by
02 **Hinweis** according to the Certificate <C>
03 **Remarque** le fait que défini dans <A> est évalué positivement par 08 **Note** as established in <A> and com o parecer positivo de de acordo com o Certificado <C>
04 **Bemerk** zoals vermeld in <A> en positief beoordeeld door 09 **Примечание** как указано в <A> и в соответствии с положительным решением 10 **Bemerk** som anført i <A> og positivt vurderet af i henhold til
Certifikat <C>

11 **Information** enligt <A> och godkänts av enligt
Certifikat <C>
12 **Merk** sonnet i teksten i <A> og gjenom positivt
bestemmelser av ifølge Serifikat <C>
13 **Huom** jotta on esitetty asiallisissa <A> ja jotta
on hyväksynyt Serifikatin <C>
14 **Poznamka** jak bylo uvedeno v <A> a pozitivně zjištěno
 v souladu s osvědčením <C>
15 **Napomena** kako je izloženo u <A> pozitivno ocijenjeno od strane
 prema Certifikatu <C>

16 **Megejorzés** a(z) <A> alapján a(z) igazolta a megjelölt, a(z) <C> tanúsítvány szerint
17 **Uveaga** zgodnie z dokumentacją <A> pozytywną
opinia i Swiadczeniem <C>
18 **Nota** așa cum este stabilit în <A> și apreciat pozitiv de 23 **Peznmes** ka notados <A> un atibatsis pozitīvajam vērtējumam
in conformitate ar Serifikatu <C>
24 **Poznamka** ako bilo udereno v <A> a pozitivne zisene v skladu s osvedcenim <C>
25 **Not** ragu on naidatu dokumenta <A> ja heaks kiidetud
 järgi vastavalt Serifikaadile <C>

21 **Zabepowia** karto e ispolzovao s <A> i ispolzovao potoporneno ot
22 **Pariba** caruacio Cerpniqvara <C>
23 **Serifikat** <C> kapnusaqia <A> i kap legemai nusaqia pagal
ka notados <A> un atibatsis pozitīvajam vērtējumam
sakarā ar Serifikatu <C>
24 **Poznamka** ako bilo udereno v <A> a pozitivne zisene v skladu s osvedcenim <C>
25 **Not** tarindam olumu olamak degertindidgi gbi.










CE - ERKLÄRUNG ÜBER SÄMISVAR
CE - LIKUTIS, YDENEKUSASUUDESTA
CE - DEKLARACJA ZGODNOSCI
CE - DECLARAȚIE DE CONFORMITATE
CE - IZJAVA O SKLADNOSTI
CE - VASTANUSDEKLARATSIOON
CE - ДЕКЛАРАЦИЯ СООТВѢТСТВИЕ
CE - DECLARAȚIE DE CONFORMITATE

09  заверяю, исключительно под свою ответственность, что оборудование, к которому относится настоящее заявление:
10  erklærer under eneansvarlig, at udsigsel, som er omfattet af denne erklæring:
11  déclare sous sa seule responsabilité, que l'équipement visé par la présente déclaration inebat at:
12  erklærer el fuldstændig ansvar for al del af udsig, som berøres af denne deklaration inebat at:
13  inibidja y kononami onalja vasuulkaan, etta tarann inibidjeen tarkoituksellaltel:
14  protidaje ve se pnie ooprednost, že državni, i kieniz se bno potidatiden vztahuje:
15  objavljam pod svojim vladnim odgovornost da opremna na koju se ova izjava odnosi:
16  bijes leuiseesse udababan kjeitni, togi a beendizeesse, mejeleke e njakidatci vortakozki:

08 esatle em conformidade com a(s) seguinte(s) norma(s) ou outro(s) documento(s) normativo(s), desde que estes sejam utilizados de
acordo com as nossas instruções:
09 соответствует следующим стандартам или другим нормативным документам, при условии их использования согласно нашим инструкциям:
10 overholder følgende standard(er) eller andetsteds tekniske dokument(er), forudsat at disse anvendes i henhold til vore instruktioner:
11 respektive utiusinging ar utiford i overensstemmelse med oth foljer folgende standard(er) eller andra normgivande dokument, under forutsattning att
användning sker i överensstemmelse med våra instruktioner:
12 respektive udsig'er i overensstemmelse med følgende standard(er) eller andre normgivende dokument(er), under forudsætning af at disse bruges i
henhold til vore instruktioner:
13 vastavaat seavaaven standardin ja muiden ohjeistien dokumentien vaatimuksia edellytetien etta nita kaytetään ohjeidemme mukaisesti:
14 za predpokladu, že jsou využity v souladu s našimi pokyny, odpovídaj následujícím normám nebo normativním dokumentům:
15 u skladu sa slijedom standardom(na) ili drugim normativnim dokumentom(na), uz uvjet da se oni koriste u skladu s našim uputama:

Low Voltage 2014/35/EU
Electromagnetic Compatibility 2014/30/EU

*

17  declare na vlastnu výhradní odpovědnost, že ujednání, kterých ta deklaracia týkajú:
18  déclare ne propre responsabilité, ce que les engagements, qui ne sont pas affectés par cette
19  z usloporotnosti javlja, da je o prema pravu, na kakvo se javia pravica:
20  kirjaltu oma täieliku vastutuse, et klasside deklaratsioon alla kulut, vastutust:
21  deklaruju na oia ooprednost, že ooborudaveto, za koro se otnas tam deklaraciu:
22  viskita sobi astomoni seobita, kad jargia, kuni takomata si deklaracia:
23  arpu alidami alidama, ka alata apastida eklarasi, uz kudem alidatasi si deklaracia:
24  vyhlásim na vlastnu zodpovednost, že zariadenie, na ktoré sa vzťahuje toto vyhlásenie
25  tánnen keniid soimulidumata oimk uzeze bu idorimni igiti oddidgi conatimimni asigidaki gbi oddidgiu beyan eder:

16 megjelöltek az alábbi szabvány (oknak vagy egy-egy irányító dokumentum(ok)nak, ha azokat előírás szerint használják:
17 szerint a miénk felelősségétől nem ijtünk dokumentumokat normalizációjáról, pod varikien ze izjavane sa zoporne s naszymi instrukcjami:
18 kni in conformitate cu unităţile (urmăreţele) standard (e) sau altele (documente) normative (e), cu condiţia ca acestea să fie utilizate în conformitate cu
instrucţiunile noastre:
19 skladni z naslednjimi standardi in drugimi normativi, pod pogojem, da se uporabijo v skladu z našimi navodili:
20 on vastavuses järgmistele standarditele ja või teiste normatiivsete dokumentidega, kui need kasutatakse vastavalt meie ühendiõtele:
21 ootavestavat na oepreite etraaputitvii dotti normatiivni dokumenti, pri usloviie, ve se ispolzovao caruacio naurite instrukcijim:
22 atitika zemaui nurodujio standardis ir (arai) kitus normiivus dokumentus su sąlyga, kad yra naudojami pagal mūsų nurodymus:
23 tad, ja lebeti atibatsis razdojia noradijumem, atibis sak oisšem standartem in oilem normatiivem dokumentem:
24 su i zibode s nasledovnoji (ymi) normoi (am) jalebo (nyim(i) normatiivny(i) dokumentom (am)), za predpokladu, že sa použivajú v sklade s našim
navodim:
25 üidutun, täimaldamuz gire kulanimasi kosjuvaja asigidaki standartiar ve norm beliten belgieleie uyumidutur:

01 Directives as amended:
02 Direktiven, gemäß Änderung:
03 Directives, telles que modifiées:
04 Richtlijnen, zoals geamendard:
05 Directives, según lo modificado:
06 Directives, come da modifica:
07 Ohjeuiv, muutetut suojenohjeet:
08 Directives, conforme à la modification en:
09 Директива, с изменением поправким:
10 Direktiver, med senere ændringer:
11 Direktiv, med foretagne ændringer:
12 Direktives, telles que modifiées:
13 Direktiveja, selaisna kun ne oia mudatiduna:
14 v rāstiem ziņā:
15 Spemica, kato je izmēģineno:
16 rājanj(e)k) es nodotlāsak izendelēzaset:
17 z pēzēspzīm jopapavimam:
18 Direktive, as amended:
19 Direktiv, med foretagne ændringer:
20 Direktiv, zoals modifiées:
21 Direktives, según lo modificado:
22 Direktives, come da modifica:
23 Ohjeuiv, muutetut suojenohjeet:
24 Directives, conforme à la modification en:
25 Директива, с изменением поправким:

| | |
|-----|-------------------|
| <A> | TCF.03.04/09-2017 |
| | DEKRA (NB0344) |
| <C> | 2192529.0551-EMC |

3P507286-2
ROTEX Heating Systems GmbH
Langwiesenstraße 10 · D-74363 Güglingen



Georg Blümel
Managing Director
2nd of October 2017

ROTEX

Table of contents

| | | | | | |
|----------|---|-----------|--|--|-----------|
| 1 | About the documentation | 3 | 6.2 | Checklist during commissioning | 21 |
| 1.1 | About this document | 3 | 6.2.1 | To check the minimum flow rate | 21 |
| 2 | About the box | 3 | 6.2.2 | To perform an air purge | 21 |
| 2.1 | Indoor unit | 3 | 6.2.3 | To perform an operation test run | 22 |
| 2.1.1 | To remove the accessories from the indoor unit | 3 | 6.2.4 | To perform an actuator test run | 22 |
| 3 | Preparation | 4 | 6.2.5 | To perform an underfloor heating screed dryout | 22 |
| 3.1 | Preparing the installation site | 4 | 7 | Hand-over to the user | 23 |
| 3.1.1 | Installation site requirements of the indoor unit | 4 | 8 | Technical data | 24 |
| 3.2 | Preparing water piping | 6 | 8.1 | Piping diagram: Indoor unit | 24 |
| 3.2.1 | To check the water volume and flow rate | 6 | 8.2 | Wiring diagram: Indoor unit | 25 |
| 3.3 | Preparing electrical wiring | 6 | 8.3 | Table 1 – Maximum refrigerant charge allowed in a room: indoor unit | 28 |
| 3.3.1 | Overview of electrical connections for external and internal actuators | 6 | 8.4 | Table 2 – Minimum floor area: indoor unit | 28 |
| 4 | Installation | 7 | 8.5 | Table 3 – Minimum venting opening area for natural ventilation: indoor unit | 28 |
| 4.1 | Opening the units | 7 | 1 | About the documentation | |
| 4.1.1 | To open the indoor unit | 7 | 1.1 | About this document | |
| 4.2 | Mounting the indoor unit | 7 | Target audience | | |
| 4.2.1 | To install the indoor unit | 7 | Authorised installers | | |
| 4.2.2 | To connect the drain hose to the drain | 8 | Documentation set | | |
| 4.3 | Connecting refrigerant piping | 8 | This document is part of a documentation set. The complete set consists of: | | |
| 4.3.1 | To connect the refrigerant piping to the indoor unit | 8 | ▪ General safety precautions: | | |
| 4.4 | Connecting water piping | 9 | ▪ Safety instructions that you must read before installing | | |
| 4.4.1 | To connect the water piping | 9 | ▪ Format: Paper (in the box of the indoor unit) | | |
| 4.4.2 | To fill the water circuit | 9 | ▪ Indoor unit installation manual: | | |
| 4.4.3 | To fill the domestic hot water tank | 9 | ▪ Installation instructions | | |
| 4.4.4 | To insulate the water piping | 9 | ▪ Format: Paper (in the box of the indoor unit) | | |
| 4.5 | Connecting the electrical wiring | 9 | ▪ Outdoor unit installation manual: | | |
| 4.5.1 | About electrical compliance | 9 | ▪ Installation instructions | | |
| 4.5.2 | To connect the electrical wiring on the indoor unit | 9 | ▪ Format: Paper (in the box of the outdoor unit) | | |
| 4.5.3 | To connect the main power supply | 10 | ▪ Installer reference guide: | | |
| 4.5.4 | To connect the backup heater power supply | 10 | ▪ Preparation of the installation, good practices, reference data,... | | |
| 4.5.5 | To connect the shut-off valve | 12 | ▪ Format: Digital files on the ROTEX homepage | | |
| 4.5.6 | To connect the electricity meters | 12 | ▪ Addendum book for optional equipment: | | |
| 4.5.7 | To connect the domestic hot water pump | 12 | ▪ Additional info about how to install optional equipment | | |
| 4.5.8 | To connect the alarm output | 12 | ▪ Format: Paper (in the box of the indoor unit) + Digital files on the ROTEX homepage | | |
| 4.5.9 | To connect the space cooling/heating ON/OFF output | 12 | Latest revisions of the supplied documentation may be available on the regional ROTEX website or via your dealer. | | |
| 4.5.10 | To connect the changeover to external heat source | 13 | The original documentation is written in English. All other languages are translations. | | |
| 4.5.11 | To connect the power consumption digital inputs | 13 | 2 | About the box | |
| 4.5.12 | To connect the safety thermostat (normally closed contact) | 13 | 2.1 | Indoor unit | |
| 4.6 | Finishing the indoor unit installation | 13 | 2.1.1 | To remove the accessories from the indoor unit | |
| 4.6.1 | To close the indoor unit | 13 | Some accessories are located inside the unit. To open the unit, see "4.1.1 To open the indoor unit" [p. 7]. | | |
| 5 | Configuration | 14 | | | |
| 5.1 | Overview: Configuration | 14 | | | |
| 5.1.1 | To access the most used commands | 14 | | | |
| 5.2 | Configuration wizard | 15 | | | |
| 5.2.1 | Configuration wizard: Language | 15 | | | |
| 5.2.2 | Configuration wizard: Time and date | 15 | | | |
| 5.2.3 | Configuration wizard: System | 15 | | | |
| 5.2.4 | Configuration wizard: Backup heater | 16 | | | |
| 5.2.5 | Configuration wizard: Main zone | 17 | | | |
| 5.2.6 | Configuration wizard: Additional zone | 18 | | | |
| 5.2.7 | Detailed screen with weather-dependent curve | 18 | | | |
| 5.2.8 | Configuration wizard: Tank | 18 | | | |
| 5.3 | Settings menu | 19 | | | |
| 5.3.1 | Main zone | 19 | | | |
| 5.3.2 | Additional zone | 19 | | | |
| 5.3.3 | Information | 19 | | | |
| 5.4 | Menu structure: Overview installer settings | 20 | | | |
| 6 | Commissioning | 21 | | | |
| 6.1 | Checklist before commissioning | 21 | | | |

3 Preparation



- a General safety precautions
- b Addendum book for optional equipment
- c Indoor unit installation manual
- d Operation manual
- e Sealing ring for shut-off valve
- f Shut-off valve
- g Overpressure bypass valve
- h Wall bracket

3 Preparation

3.1 Preparing the installation site



WARNING

The appliance shall be stored in a room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater).




WARNING

DO NOT reuse refrigerant piping that has been used with any other refrigerant. Replace the refrigerant pipes or clean thoroughly.

3.1.1 Installation site requirements of the indoor unit

- The indoor unit is designed for indoor installation only and for the following ambient temperatures:
 - Space heating operation: 5~30°C
 - Space cooling operation: 5~35°C
 - Domestic hot water production: 5~35°C
- Mind the following spacing installation guidelines:



H Height measured from the bottom of the casing to the floor

Special requirements for R32



WARNING

- Do NOT pierce or burn.
- Do NOT use means to accelerate the defrosting process or to clean the equipment, other than those recommended by the manufacturer.
- Be aware that R32 refrigerant does NOT contain an odour.



WARNING

The appliance shall be stored so as to prevent mechanical damage and in a well-ventilated room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater) and have a room size as specified below.



NOTICE

- Do NOT re-use joints which have been used already.
- Joints made in installation between parts of refrigerant system shall be accessible for maintenance purposes.



WARNING

Make sure installation, servicing, maintenance and repair comply with instructions from ROTEX and with applicable legislation (for example national gas regulation) and are executed only by authorised persons.



NOTICE

- Pipework shall be protected from physical damage.
- Installation of pipework shall be kept to a minimum.


If the total refrigerant charge in the system is ≥ 1.84 kg (i.e. if the piping length is ≥ 27 m), you need to comply with the minimum floor area requirements as described in the following flow chart. The flow chart uses the following tables: "8.3 Table 1 – Maximum refrigerant charge allowed in a room: indoor unit" [p 28], "8.4 Table 2 – Minimum floor area: indoor unit" [p 28] and "8.5 Table 3 – Minimum venting opening area for natural ventilation: indoor unit" [p 28].

i INFORMATION

Systems with a total refrigerant charge (m_c) < 1.84 kg (i.e. if the piping length is < 27 m) are NOT subjected to any requirements to the installation room.

i INFORMATION

Multiple indoor units. If two or more indoor units are installed in a room, you must consider the maximum refrigerant charge that can be released in the room when a SINGLE leak occurs. **Example:** If two indoor units are installed in the room, each with its own outdoor unit, then you have to consider the refrigerant charge of the largest indoor-outdoor combination.



3 Preparation

3.2 Preparing water piping

NOTICE

In case of plastic pipes, make sure they are fully oxygen diffusion tight according to DIN 4726. The diffusion of oxygen into the piping can lead to excessive corrosion.

- **Valve towards expansion vessel.** The valve towards the expansion vessel (if equipped) MUST be open.

3.2.1 To check the water volume and flow rate

Minimum water volume

Check that the total water volume in the installation is minimum 10 litres, the internal water volume of the indoor unit NOT included.

NOTICE

When circulation in each space heating/cooling loop is controlled by remotely controlled valves, it is important that the minimum water volume is guaranteed, even if all of the valves are closed.

Minimum flow rate

Check that the minimum flow rate in the installation is guaranteed in all conditions. This minimum flow rate is required during defrost/backup heater operation. For this purpose, use the overpressure bypass valve delivered with the unit, and respect the minimum water volume.

NOTICE

When circulation in each or certain space heating loops is controlled by remotely controlled valves, it is important that the minimum flow rate is guaranteed, even if all valves are closed. In case the minimum flow rate cannot be reached, a flow error 7H will be generated (no heating or operation).

See the installer reference guide for more information.

Minimum required flow rate

12 l/min

See the recommended procedure as described in "6.2 Checklist during commissioning" [p 21].

3.3 Preparing electrical wiring

3.3.1 Overview of electrical connections for external and internal actuators

| Item | Description | Wires | Maximum running current |
|--|---|------------------|-------------------------|
| Outdoor unit and indoor unit power supply | | | |
| 1 | Power supply for outdoor unit | 2+GND | (a) |
| 2 | Power supply and interconnection cable to indoor unit | 3 | (g) |
| 3 | Power supply for backup heater | See table below. | — |
| 4 | Preferential kWh rate power supply (voltage free contact) | 2 | (e) |
| 5 | Normal kWh rate power supply | 2 | 6.3 A |
| Optional equipment | | | |
| 6 | 3-way valve | 3 | 100 mA ^(b) |

| Item | Description | Wires | Maximum running current |
|----------------------------------|---|----------------------|-------------------------|
| 7 | Power supply for booster heater and thermal protection (from indoor unit) | 4+GND | (c) |
| 8 | Power supply for booster heater (to indoor unit) | 2+GND | 13 A |
| 9 | Domestic hot water tank thermistor | 2 | (d) |
| 10 | User interface used as room thermostat | 2 | (f) |
| 11 | Room thermostat | 3 or 4 | 100 mA ^(b) |
| 12 | Outdoor ambient temperature sensor | 2 | (b) |
| 13 | Indoor ambient temperature sensor | 2 | (b) |
| 14 | Heat pump convector | 2 | 100 mA ^(b) |
| Field supplied components | | | |
| 15 | Shut-off valve | 2 | 100 mA ^(b) |
| 16 | Electricity meter | 2 (per meter) | (b) |
| 17 | Domestic hot water pump | 2 | (b) |
| 18 | Alarm output | 2 | (b) |
| 19 | Changeover to external heat source control | 2 | (b) |
| 20 | Space cool/heat operation control | 2 | (b) |
| 21 | Power consumption digital inputs | 2 (per input signal) | (b) |
| 22 | Safety thermostat | 2 | (e) |

- (a) Refer to name plate on outdoor unit.
 (b) Minimum cable section 0.75 mm².
 (c) Cable section 2.5 mm².
 (d) The thermistor and connection wire (12 m) are delivered with the domestic hot water tank.
 (e) Cable section 0.75 mm² till 1.25 mm²; maximum length: 50 m. Voltage-free contact shall ensure the minimum applicable load of 15 V DC, 10 mA.
 (f) Cable section 0.75 mm² till 1.25 mm²; maximum length: 500 m. Applicable for both single user interface and dual user interface connection.
 (g) Cable section 1.5 mm².



NOTICE

More technical specifications of the different connections are indicated on the inside of the indoor unit.


| Backup heater type | Power supply | Required number of conductors |
|--------------------|----------------|-------------------------------|
| *6V | 1N~ 230 V (6V) | 2+GND |
| | 3~ 230 V (6T1) | 3+GND |
| *9W | 3N~ 400 V | 4+GND |

4 Installation

4.1 Opening the units

4.1.1 To open the indoor unit


Overview




- 1 Front panel
- 2 Switch box cover
- 3 Switch box
- 4 User interface panel

Open


- 1 Remove the front panel.




- 2 If you have to connect electrical wiring, remove the switch box cover.



- 3 If you have to do work behind the switch box, open the switch box.



- 4 If you have to do work behind the user interface panel or upload new software into the user interface, open the user interface panel.




- 5 Optional: Remove the user interface panel.



NOTICE

If you remove the user interface panel, also disconnect the cables from the back of the user interface panel to prevent damage.




4.2 Mounting the indoor unit

4.2.1 To install the indoor unit


- 1 Fix the wall bracket (accessory) to the wall (level) with 2 Ø8 mm bolts.

4 Installation




a Optional: If you want to fix the unit to the wall from inside the unit, provide an additional screw plug.

2 Lift the unit.




3 Attach the unit to the wall bracket:

- Tilt the top of the unit against the wall at the position of the wall bracket.
- Slide the bracket on the back of the unit over the wall bracket. Make sure the unit is fixed properly.



4 Optional: If you want to fix the unit to the wall from inside the unit:


- Remove the upper front panel, and open the switch box. See "4.1.1 To open the indoor unit" [p 7].
- Fix the unit to the wall with an Ø8 mm screw.



4.2.2 To connect the drain hose to the drain

Water coming from the pressure relief valve is collected in the drain pan. You must connect the drain pan to an appropriate drain according to the applicable legislation.

1 Connect a drain tube (field supply) to the drain pan connector as follows:



a Drain pan connector


It is recommended to use a tundish to collect the water.

4.3 Connecting refrigerant piping

See the installation manual of the outdoor unit for all guidelines, specifications and installation instructions.

4.3.1 To connect the refrigerant piping to the indoor unit

1 Connect the liquid stop valve from the outdoor unit to the refrigerant liquid connection of the indoor unit.



a Refrigerant liquid connection
b Refrigerant gas connection

2 Connect the gas stop valve from the outdoor unit to the refrigerant gas connection of the indoor unit.

4.4 Connecting water piping

4.4.1 To connect the water piping




NOTICE

Do NOT use excessive force when connecting the piping. Deformation of the piping can cause malfunctioning of the unit.

To facilitate service and maintenance, 2 shut-off valves and 1 overpressure bypass valve are provided. Mount the shut-off valves on the space heating water inlet and space heating water outlet. To ensure the minimum flow rate (and prevent overpressure), install the overpressure bypass valve on the space heating water outlet.

- 1 Install the shut-off valves on the water pipes.



- a Water inlet
- b Water outlet
- c Shut-off valve
- d O-ring

- 2 Screw the indoor unit nuts on the shut-off valves.
- 3 Connect the field piping on the shut-off valves.
- 4 In case of connection with the optional domestic hot water tank, see the installation manual of the domestic hot water tank.



NOTICE

Install air purge valves at all local high points.



NOTICE



Overpressure bypass valve (delivered as accessory). We recommend to install the overpressure bypass valve in the space heating water circuit.

- Mind the minimum water volume when choosing the installation location of the overpressure bypass valve (at the indoor unit, or at the collector). See ["3.2.1 To check the water volume and flow rate"](#) [p 6].
- Mind the minimum flow rate when adjusting the overpressure bypass valve setting. See ["3.2.1 To check the water volume and flow rate"](#) [p 6] and ["6.2.1 To check the minimum flow rate"](#) [p 21].



NOTICE

In case an optional domestic hot water tank is installed: A pressure relief valve (field supply) with an opening pressure of maximum 10 bar (= 1 MPa) must be installed on the domestic cold water inlet connection in accordance with the applicable legislation.

4.4.2 To fill the water circuit

To fill the water circuit, use a field supply filling kit. Make sure you comply with the applicable legislation.



INFORMATION

Make sure both air purge valves (one on the magnetic filter and one on the backup heater) are open.

4.4.3 To fill the domestic hot water tank

See the installation manual of the domestic hot water tank.

4.4.4 To insulate the water piping

The piping in the complete water circuit **MUST** be insulated to prevent condensation during cooling operation and reduction of the heating and cooling capacity.

If the temperature is higher than 30°C and the humidity is higher than RH 80%, the thickness of the insulation materials should be at least 20 mm to prevent condensation on the surface of the insulation.

4.5 Connecting the electrical wiring



DANGER: RISK OF ELECTROCUTION



WARNING

ALWAYS use multicore cable for power supply cables.


4.5.1 About electrical compliance

Only for the backup heater of the indoor unit


See ["4.5.4 To connect the backup heater power supply"](#) [p 10].

4.5.2 To connect the electrical wiring on the indoor unit

- 1 Open the switch box so that you can access the back of the switch box. See ["4.1.1 To open the indoor unit"](#) [p 7].
- 2 Route the wiring as follows:
 - Enter the unit from the bottom.
 - Route the wiring via the back of the switch box.
 - Fix the cables with cable ties to the cable tie mountings at the back of the switch box.



- a, b, c Field wiring (see table below)
- d Factory-mounted cable for power supply of backup heater
- e Factory-mounted cable for power supply of booster heater



4 Installation



INFORMATION

When installing field supply or option cables, foresee sufficient cable length. This will make it possible to open the switch box and gain access to other components during service.

| Routing | Possible cables (depending on unit type and installed options) |
|--|--|
| a Low voltage | <ul style="list-style-type: none"> ▪ Preferential power supply contact ▪ User interface used as room thermostat (option) ▪ Power consumption digital inputs (field supply) ▪ Outdoor ambient temperature sensor (option) ▪ Indoor ambient temperature sensor (option) ▪ Electrical meters (field supply) ▪ Safety thermostat (field supply) |
| b High voltage power supply | <ul style="list-style-type: none"> ▪ Interconnection cable ▪ Normal kWh rate power supply ▪ Preferential kWh rate power supply |
| c High voltage control signal | <ul style="list-style-type: none"> ▪ Heat pump convactor (option) ▪ Room thermostat (option) ▪ Shut-off valve (field supply) ▪ Domestic hot water pump (field supply) ▪ Alarm output ▪ Changeover to external heat source control ▪ Space cool/heat operation control |
| d High voltage power supply (factory-mounted cable) | <ul style="list-style-type: none"> ▪ Power supply for backup heater |
| e High voltage power supply (factory-mounted cable) | <ul style="list-style-type: none"> ▪ Power supply for booster heater |




CAUTION

Do NOT push or place redundant cable length in the unit.

4.5.3 To connect the main power supply

- 1 Connect the main power supply.


In case of normal kWh rate power supply



a Interconnection cable (=main power supply)

In case of preferential kWh rate power supply

Connect X11Y to X11YB.



- a Interconnection cable (=main power supply)
b Normal kWh rate power supply
c Preferential power supply contact

- 2 Fix the cables with cable ties to the cable tie mountings.



INFORMATION

In case of preferential kWh rate power supply, connect X11Y to X11YB. The necessity of separate normal kWh rate power supply to indoor unit (b) X2M/5+6 depends on the type of preferential kWh rate power supply.

Separate connection to the indoor unit is required:

- if preferential kWh rate power supply is interrupted when active, OR
- if no power consumption of the indoor unit is allowed at the preferential kWh rate power supply when active.



INFORMATION

The preferential kWh rate power supply contact is connected to the same terminals (X5M/9+10) as the safety thermostat. Thus, the system can have EITHER preferential kWh rate power supply OR a safety thermostat.

4.5.4 To connect the backup heater power supply



CAUTION

If the indoor unit has a tank with a built-in electrical booster heater, use a dedicated power circuit for the backup heater and booster heater. NEVER use a power circuit shared by another appliance. This power circuit MUST be protected with the required safety devices according to the applicable legislation.



CAUTION


To guarantee the unit is completely earthed, always connect the backup heater power supply and the earth cable.

The backup heater capacity can vary, depending on the indoor unit model. Make sure that the power supply is in accordance with the backup heater capacity, as listed in the table below.

| Backup heater type | Backup heater capacity | Power supply | Maximum running current | Z_{max} |
|--------------------|------------------------|--------------------------|-------------------------|---------------|
| *6V | 2 kW | 1N~ 230 V ^(c) | 9 A | — |
| | 4 kW | 1N~ 230 V ^(c) | 17 A ^{(a)(b)} | 0.22 Ω |
| | 6 kW | 1N~ 230 V ^(c) | 26 A ^{(a)(b)} | 0.22 Ω |
| | 2 kW | 3~ 230 V ^(d) | 5 A | — |
| | 4 kW | 3~ 230 V ^(d) | 10 A | — |
| | 6 kW | 3~ 230 V ^(d) | 15 A | — |
| *9W | 3 kW | 3N~ 400 V | 4 A | — |
| | 6 kW | 3N~ 400 V | 9 A | — |
| | 9 kW | 3N~ 400 V | 13 A | — |

- (a) Equipment complying with EN/IEC 61000-3-12 (European/International Technical Standard setting the limits for harmonic currents produced by equipment connected to public low-voltage systems with input current >16 A and ≤75 A per phase.).
- (b) This equipment complies with EN/IEC 61000-3-11 (European/International Technical Standard setting the limits for voltage changes, voltage fluctuations and flicker in public low-voltage supply systems for equipment with rated current ≤75 A) provided that the system impedance Z_{sys} is less than or equal to Z_{max} at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a system impedance Z_{sys} less than or equal to Z_{max} .
- (c) (6V)
- (d) (6T1)

Connect the backup heater power supply as follows:



- a Factory-mounted cable connected to the backup heater contactor inside the switch box (K5M for *6V and *9W models)
- b Field wiring (see table below)

| Model (power supply) | Connections to backup heater power supply |
|----------------------|---|
| *6V (6V: 1N~ 230 V) | |
| *6V (6T1: 3~ 230 V) | |
| *9W (3N~ 400 V) | |

F1B Overcurrent fuse (field supply). Recommended fuse for *6V and *9W models: 4-pole; 20 A; curve 400 V; tripping class C.

K1M Contactor (in the switch box)
K5M Safety contactor (in the switch box)
Q1DI Earth leakage circuit breaker (field supply)
SWB Switch box
X6M Terminal (field supply)

4 Installation



NOTICE

Do NOT cut or remove the backup heater power supply cable.

4.5.5 To connect the shut-off valve



INFORMATION


Shut-off valve usage example. In case of one LWT zone, and a combination of underfloor heating and heat pump convectors, install a shut-off valve before the underfloor heating to prevent condensation on the floor during cooling operation. For more information, see the installer reference guide.

- 1 Connect the valve control cable to the appropriate terminals as shown in the illustration below.



NOTICE

Wiring is different for a NC (normally closed) valve and a NO (normally open) valve.



- 2 Fix the cable with cable ties to the cable tie mountings.


4.5.6 To connect the electricity meters



INFORMATION

In case of an electricity meter with transistor output, check the polarity. The positive polarity MUST be connected to X5M/6 and X5M/4; the negative polarity to X5M/5 and X5M/3.


- 1 Connect the electricity meters cable to the appropriate terminals as shown in the illustration below.



- 2 Fix the cable with cable ties to the cable tie mountings.

4.5.7 To connect the domestic hot water pump


- 1 Connect the domestic hot water pump cable to the appropriate terminals as shown in the illustration below.



- 2 Fix the cable with cable ties to the cable tie mountings.

4.5.8 To connect the alarm output

- 1 Connect the alarm output cable to the appropriate terminals as shown in the illustration below.




a Installation of EKR1HBAA is required.

- 2 Fix the cable with cable ties to the cable tie mountings.

4.5.9 To connect the space cooling/heating ON/OFF output

- 1 Connect the space cooling/heating ON/OFF output cable to the appropriate terminals as shown in the illustration below.




a Installation of EKR1HBAA is required.

- 2 Fix the cable with cable ties to the cable tie mountings.

4.5.10 To connect the changeover to external heat source

- 1 Connect the changeover to external heat source cable to the appropriate terminals as shown in the illustration below.




a Installation of EKR1HBAA is required.

- 2 Fix the cable with cable ties to the cable tie mountings.

4.5.11 To connect the power consumption digital inputs

- 1 Connect the power consumption digital inputs cable to the appropriate terminals as shown in the illustration below.




a Installation of EKR1AHTA is required.

- 2 Fix the cable with cable ties to the cable tie mountings.

4.5.12 To connect the safety thermostat (normally closed contact)

- 1 Connect the safety thermostat (normally closed) cable to the appropriate terminals as shown in the illustration below.



- 2 Fix the cable with cable ties to the cable tie mountings.



NOTICE

Make sure to select and install the safety thermostat according to the applicable legislation.

In any case, to prevent unnecessary tripping of the safety thermostat, we recommend the following:

- The safety thermostat is automatically resettable.
- The safety thermostat has a maximum temperature variation rate of 2°C/min.
- There is a minimum distance of 2 m between the safety thermostat and the motorized 3-way valve delivered with the domestic hot water tank.



INFORMATION

ALWAYS configure the safety thermostat after its installation. Without configuration, the indoor unit will ignore the safety thermostat contact.



INFORMATION

The preferential kWh rate power supply contact is connected to the same terminals (X5M/9+10) as the safety thermostat. Thus, the system can have EITHER preferential kWh rate power supply OR a safety thermostat.

4.6 Finishing the indoor unit installation

4.6.1 To close the indoor unit

- 1 Reinstall the user interface panel.
- 2 Reinstall the switch box cover and close the switch box.
- 3 Reinstall the front panel.

5 Configuration



NOTICE

When closing the indoor unit cover, make sure that the tightening torque does NOT exceed 4.1 N•m.

5 Configuration

5.1 Overview: Configuration

This chapter describes what you have to do and know to configure the system after it is installed.



NOTICE

The explanation about the configuration in this chapter gives you **ONLY** basic explanations. For more detailed explanation and background information, see the installer reference guide.

Why

If you do NOT configure the system correctly, it might NOT work as expected. The configuration influences the following:

- The calculations of the software
- What you can see on and do with the user interface

How

You can configure the system via the user interface.

- **First time – Configuration wizard.** When you turn ON the user interface for the first time (via the indoor unit), the configuration wizard starts to help you configure the system.
- **Restart the configuration wizard.** If the system is already configured, you can restart the configuration wizard. To restart the configuration wizard, go to Installer settings > Configuration wizard. To access Installer settings, see ["5.1.1 To access the most used commands"](#) [p 14].
- **Afterwards.** If necessary, you can make changes to the configuration in the menu structure or the overview settings.



INFORMATION

When the configuration wizard is finished, the user interface will show an overview screen and request to confirm. When confirmed, the system will restart and the home screen will be displayed.

Accessing settings – Legend for tables

You can access the installer settings using two different methods. However, NOT all settings are accessible via both methods. If so, the corresponding table columns in this chapter are set to N/A (not applicable).

| Method | Column in tables |
|---|---------------------------------------|
| Accessing settings via the breadcrumb in the home menu screen or the menu structure . To enable breadcrumbs, press the ? button in the home screen. | # For example: [9.1.5.2] |
| Accessing settings via the code in the overview field settings . | Code For example: [C-07] |

See also:

- ["To access the installer settings"](#) [p 14]
- ["5.4 Menu structure: Overview installer settings"](#) [p 20]

5.1.1 To access the most used commands


To change the user permission level

You can change the user permission level as follows:

| | | |
|---|--|---|
| 1 | Go to [B]: User profile. | |
| 2 | Enter the applicable pin code for the user permission level. | — |
| | ▪ Browse through the list of digits and change the selected digit. | |
| | ▪ Move the cursor from left to right. | |
| | ▪ Confirm the pin code and proceed. | |


Installer pin code

The Installer pin code is **5678**. Additional menu items and installer settings are now available.




Advanced user pin code

The Advanced user pin code is **1234**. Additional menu items for the user are now visible.



User pin code

The User pin code is **0000**.



To access the installer settings

- 1 Set the user permission level to Installer.
- 2 Go to [9]: Installer settings.

To modify an overview setting

Example: Modify [1-01] from 15 to 20.

Most settings can be configured via the menu structure. If for any reason it is required to change a setting using the overview settings, then the overview settings can be accessed as follows:

| | | |
|---|---|---|
| 1 | Set the user permission level to Installer. See "To change the user permission level" [p 14]. | — |
| 2 | Go to [9.1]: Installer settings > Overview field settings. | |

| | | | | | | | | | | | | | | | | | |
|----|--|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|--|
| 3 | Turn the left dial to select the first part of the setting and confirm by pressing the dial. | | | | | | | | | | | | | | | | |
| | <table border="1"> <tr><td>00</td><td>05</td><td>0A</td></tr> <tr><td>01</td><td>06</td><td>0B</td></tr> <tr><td>02</td><td>07</td><td>0C</td></tr> <tr><td>03</td><td>08</td><td>0D</td></tr> <tr><td>04</td><td>09</td><td>0E</td></tr> </table> | 00 | 05 | 0A | 01 | 06 | 0B | 02 | 07 | 0C | 03 | 08 | 0D | 04 | 09 | 0E | |
| 00 | 05 | 0A | | | | | | | | | | | | | | | |
| 01 | 06 | 0B | | | | | | | | | | | | | | | |
| 02 | 07 | 0C | | | | | | | | | | | | | | | |
| 03 | 08 | 0D | | | | | | | | | | | | | | | |
| 04 | 09 | 0E | | | | | | | | | | | | | | | |
| 4 | Turn the left dial to select the second part of the setting | | | | | | | | | | | | | | | | |
| | <table border="1"> <tr><td>00</td><td>05</td><td>0A</td></tr> <tr><td>01</td><td>15</td><td>0B</td></tr> <tr><td>02</td><td>07</td><td>0C</td></tr> <tr><td>03</td><td>08</td><td>0D</td></tr> <tr><td>04</td><td>09</td><td>0E</td></tr> </table> | 00 | 05 | 0A | 01 | 15 | 0B | 02 | 07 | 0C | 03 | 08 | 0D | 04 | 09 | 0E | |
| 00 | 05 | 0A | | | | | | | | | | | | | | | |
| 01 | 15 | 0B | | | | | | | | | | | | | | | |
| 02 | 07 | 0C | | | | | | | | | | | | | | | |
| 03 | 08 | 0D | | | | | | | | | | | | | | | |
| 04 | 09 | 0E | | | | | | | | | | | | | | | |
| 5 | Turn the right dial to modify the value from 15 to 20. | | | | | | | | | | | | | | | | |
| | <table border="1"> <tr><td>00</td><td>05</td><td>0A</td></tr> <tr><td>01</td><td>20</td><td>0B</td></tr> <tr><td>02</td><td>07</td><td>0C</td></tr> <tr><td>03</td><td>08</td><td>0D</td></tr> <tr><td>04</td><td>09</td><td>0E</td></tr> </table> | 00 | 05 | 0A | 01 | 20 | 0B | 02 | 07 | 0C | 03 | 08 | 0D | 04 | 09 | 0E | |
| 00 | 05 | 0A | | | | | | | | | | | | | | | |
| 01 | 20 | 0B | | | | | | | | | | | | | | | |
| 02 | 07 | 0C | | | | | | | | | | | | | | | |
| 03 | 08 | 0D | | | | | | | | | | | | | | | |
| 04 | 09 | 0E | | | | | | | | | | | | | | | |
| 6 | Press the left dial to confirm the new setting. | | | | | | | | | | | | | | | | |
| 7 | Press the center button to go back to the home screen. | | | | | | | | | | | | | | | | |

**INFORMATION**

When you change the overview settings and you go back to the home screen, the user interface will show a popup screen and request to restart the system.

When confirmed, the system will restart and recent changes will be applied.

5.2 Configuration wizard

After first power ON of the system, the user interface will guide you using the configuration wizard. This way you can set the most important initial settings. This way the unit will be able to run properly. Afterwards, more detailed settings can be done via the menu structure if required.

5.2.1 Configuration wizard: Language

| # | Code | Description |
|-------|------|-------------|
| [7.1] | N/A | Language |

5.2.2 Configuration wizard: Time and date

| # | Code | Description |
|-------|------|-----------------------------|
| [7.2] | N/A | Set the local time and date |

**INFORMATION**

By default, daylight savings time is enabled and clock format is set to 24 hours. If you want to change these settings, you can do this in the menu structure (User settings > Time/date) once the unit is initialised.

5.2.3 Configuration wizard: System

Indoor unit type

The indoor unit type is displayed, but cannot be adjusted.

Backup heater type

The backup heater is adapted to be connected to most common European electricity grids. The type of backup heater must be set on the user interface. For units with a built-in backup heater, the type of heater can be viewed but not changed.

| # | Code | Description |
|---------|--------|---|
| [9.3.1] | [E-03] | <ul style="list-style-type: none"> 2: 3V 3: 6V 4: 9W |

Domestic hot water

The following setting determines if the system can prepare domestic hot water or not, and which tank is used. Set this setting according to the actual installation.

| # | Code | Description |
|---------|---|---|
| [9.2.1] | [E-05] ^(a) [E-06] ^(a) [E-07] ^(a) | <ul style="list-style-type: none"> No DHW No tank installed. EKHWS/E Tank with booster heater installed at the side of the tank. EKHWP/HYC Tank with optional booster heater installed at the top of the tank. |

^(a) Use the menu structure instead of the overview settings.

Menu structure setting [9.2.1] replaces the following 3 overview settings:

- [E-05]: Can the system prepare domestic hot water?
- [E-06]: Is a domestic hot water tank installed in the system?
- [E-07]: What kind of domestic hot water tank is installed?

In case of EKHWP/HYC, we recommend to set the temperature of the booster heater NOT higher than 70°C.

In case of !!!!! NO ROTEX AVAILABLE !!!!! / !!!!! NO ROTEX AVAILABLE !!!!!, we recommend to use the following settings:

| # | Code | Item | !!!! NO ROTEX AVAILABLE !!!!! / !!!!! NO ROTEX AVAILABLE !!!!! | |
|---------|--------|--------------------------|--|--------------|
| | | | 150/180 | 200/250/300 |
| [9.2.1] | [E-07] | Tank type | 0: EKHWS/E | 5: EKHWP/HYC |
| N/A | [4-05] | Thermistor type | 0: Automatic | 1: Type 1 |
| [5.8] | [6-0E] | Maximum tank temperature | ≤75°C | |

Emergency

When the heat pump fails to operate, the backup heater and/or booster heater can serve as an emergency heater and take over the heat load either automatically or by manual interaction.

- When Emergency is set to Automatic and a heat pump failure occurs:
 - the backup heater automatically takes over the heat load,
 - the booster heater in the optional tank automatically takes over the domestic hot water production.
- When Emergency is set to Manual and a heat pump failure occurs, the domestic hot water and space heating operation stops. To manually recover it via the user interface, go to the Malfunctioning main menu screen and confirm whether the backup heater and/or booster heater can take over the heat load or not.

We recommend to set Emergency to Automatic if the house is unattended for longer periods.

5 Configuration

| # | Code | Description |
|-------|------|---|
| [9.5] | N/A | <ul style="list-style-type: none"> 0: Manual 1: Automatic |



INFORMATION

The auto emergency setting can be set in the menu structure of the user interface only.



INFORMATION

If [4-03]=1 or 3, then Emergency = Manual is not applicable for the booster heater.





INFORMATION

If a heat pump failure occurs and Emergency is set to Manual, the room frost protection function, the underfloor heating screed dryout function, and the water pipe antifreeze function will remain active even if the user does NOT confirm emergency operation.

Number of zones

The system can supply leaving water to up to 2 water temperature zones. During configuration, the number of water zones must be set.

| # | Code | Description |
|-------|--------|---|
| [4.4] | [7-02] | <ul style="list-style-type: none"> 0: Single zone <p>Only one leaving water temperature zone:</p>  <p>a Main LWT zone</p> |
| [4.4] | [7-02] | <ul style="list-style-type: none"> 1: Dual zone <p>Two leaving water temperature zones. The main leaving water temperature zone consists of the higher load heat emitters and a mixing station to achieve the desired leaving water temperature. In heating:</p>  <p>a Additional LWT zone: Highest temperature b Main LWT zone: Lowest temperature c Mixing station</p> |



CAUTION

NOT configuring the system in the following way can cause damage to the heat emitters. If there are 2 zones, it is important that in heating:

- the zone with the lowest water temperature is configured as the main zone, and
- the zone with the highest water temperature is configured as the additional zone.



CAUTION

If there are 2 zones and the emitter types are wrongly configured, water of high temperature can be sent towards a low temperature emitter (underfloor heating). To avoid this:

- Install an aquastat/thermostatic valve to avoid too high temperatures towards a low temperature emitter.
- Make sure you set the emitter types for the main zone [2.7] and for the additional zone [3.7] correctly in accordance with the connected emitter.



NOTICE

An overpressure bypass valve can be integrated in the system. Keep in mind that this valve might not be shown on the illustrations.

5.2.4 Configuration wizard: Backup heater

The backup heater is adapted to be connected to most common European electricity grids. If the backup heater is available, the voltage, configuration and capacity must be set on the user interface.

The capacities for the different steps of the backup heater must be set for the energy metering and/or power consumption control feature to work properly. When measuring the resistance value of each heater, you can set the exact heater capacity and this will lead to more accurate energy data.

Voltage

- For a 3V model, this is fixed to 230V, 1ph.
- For a 6V model, this can be set to:
 - 230V, 1ph
 - 230V, 3ph
- For a 9W model, this is fixed to 400V, 3ph.

| # | Code | Description |
|---------|--------|--|
| [9.3.2] | [5-0D] | <ul style="list-style-type: none"> 0: 230V, 1ph 1: 230V, 3ph 2: 400V, 3ph |

Configuration

The backup heater can be configured in different ways. It can be chosen to have a 1-step only backup heater or a backup heater with 2 steps. If 2 steps, the capacity of the second step depends on this setting. It can also be chosen to have a higher capacity of the second step in emergency.

| # | Code | Description |
|---------|--------|--|
| [9.3.3] | [4-0A] | <ul style="list-style-type: none"> 0: Relay 1 1: Relay 1 / Relay 1+2^(a) 2: Relay 1 / Relay 2^(a) 3: Relay 1 / Relay 2 Emergency Relay 1+2^(a) |

(a) Not available for 3V models.

**INFORMATION**

Settings [9.3.3] and [9.3.5] are linked. Changing one setting influences the other. If you change one, check if the other is still as expected.

**INFORMATION**

During normal operation, the capacity of the second step of the backup heater at nominal voltage is equal to [6-03]+[6-04].

**INFORMATION**

If [4-0A]=3 and emergency mode is active, the power usage of the backup heater is maximal and equal to 2×[6-03]+[6-04].

Capacity step 1

| # | Code | Description |
|---------|--------|---|
| [9.3.4] | [6-03] | <ul style="list-style-type: none"> The capacity of the first step of the backup heater at nominal voltage. |

Additional capacity step 2

| # | Code | Description |
|---------|--------|--|
| [9.3.5] | [6-04] | <ul style="list-style-type: none"> The capacity difference between the second and first step of the backup heater at nominal voltage. Nominal value depends on backup heater configuration. |

5.2.5 Configuration wizard: Main zone

The most important settings for the main leaving water zone can be set here.

Emitter type

Heating up or cooling down the main zone can take longer. This depends on:

- The water volume of the system
- The heater emitter type of the main zone

The setting **Emitter type** can compensate for a slow or a quick heating/cooling system during the heat up/cool down cycle. In room thermostat control, **Emitter type** influences the maximum modulation of the desired leaving water temperature, and the possibility for usage of the automatic cooling/heating changeover based on the indoor ambient temperature.

It is important to set **Emitter type** correctly and in accordance with your system layout. The target delta T for the main zone depends on it.

| # | Code | Description |
|-------|--------|---|
| [2.7] | [2-0C] | <ul style="list-style-type: none"> 0: Underfloor heating 1: Fancoil unit 2: Radiator |

The setting of the emitter type has an influence on the space heating setpoint range and the target delta T in heating as follows:

| Description | Space heating setpoint range | Target delta T in heating |
|-----------------------|------------------------------|---------------------------|
| 0: Underfloor heating | Maximum 55°C | Variable |
| 1: Fancoil unit | Maximum 55°C | Variable |
| 2: Radiator | Maximum 65°C | Fixed 10°C |

**NOTICE**

For radiators, the average emitter temperature will be lower compared to underfloor heating, due to the fixed delta T of 10°C. To compensate, you can:

- Increase the weather dependent curve desired temperatures [2.5].
- Enable leaving water temperature modulation and increase the maximum modulation [2.C].

Control

Define how the operation of the unit is controlled.

| Control | In this control... |
|--------------------------|---|
| Leaving water | Unit operation is decided based on the leaving water temperature regardless the actual room temperature and/or heating or cooling demand of the room. |
| External room thermostat | Unit operation is decided by the external thermostat or equivalent (e.g. heat pump convector). |
| Room thermostat | Unit operation is decided based on the ambient temperature of the user interface used as a room thermostat. |

| # | Code | Description |
|-------|--------|---|
| [2.9] | [C-07] | <ul style="list-style-type: none"> 0: Leaving water 1: External room thermostat 2: Room thermostat |

Setpoint mode

Define the setpoint mode:

- **Fixed:** the desired leaving water temperature does not depend on the outdoor ambient temperature.
- **In WD heating, fixed cooling mode,** the desired leaving water temperature:
 - depends on the outdoor ambient temperature for heating
 - does NOT depend on the outdoor ambient temperature for cooling
- **In Weather dependent mode,** the desired leaving water temperature depends on the outdoor ambient temperature.

| # | Code | Description |
|-------|------|---|
| [2.4] | N/A | Setpoint mode <ul style="list-style-type: none"> Fixed WD heating, fixed cooling Weather dependent |

When weather dependent operation is active, low outdoor temperatures will result in warmer water and vice versa. During weather dependent operation, the user can shift the water temperature up or down by a maximum of 10°C.

Schedule

Indicates if the desired leaving water temperature is according to a schedule. Influence of the LWT setpoint mode [2.4] is as follows:

- In **Fixed** LWT setpoint mode, the scheduled actions consist of desired leaving water temperatures, either preset or custom.
- In **Weather dependent** LWT setpoint mode, the scheduled actions consist of desired shift actions, either preset or custom.

| # | Code | Description |
|-------|------|---|
| [2.1] | N/A | <ul style="list-style-type: none"> 0: No 1: Yes |

5 Configuration

5.2.6 Configuration wizard: Additional zone

The most important settings for the additional leaving water zone can be set here.

Emitter type

For more info about this functionality, see ["5.2.5 Configuration wizard: Main zone" \[p 17\]](#).

| # | Code | Description |
|-------|--------|---|
| [3.7] | [2-0D] | <ul style="list-style-type: none"> 0: Underfloor heating 1: Fancoil unit 2: Radiator |

Control

The control type is displayed here, but cannot be adjusted. It is determined by the control type of the main zone. For more info about the functionality, see ["5.2.5 Configuration wizard: Main zone" \[p 17\]](#).

| # | Code | Description |
|-------|------|---|
| [3.9] | N/A | <ul style="list-style-type: none"> 0: Leaving water if the control type of the main zone is Leaving water. 1: External room thermostat if the control type of the main zone is External room thermostat or Room thermostat. |

Setpoint mode

For more info about this functionality, see ["5.2.5 Configuration wizard: Main zone" \[p 17\]](#).

| # | Code | Description |
|-------|------|--|
| [3.4] | N/A | <ul style="list-style-type: none"> 0: Fixed 1: WD heating, fixed cooling 2: Weather dependent |

If you choose WD heating, fixed cooling or Weather dependent, the next screen will be the detailed screen with weather-dependent curves. Also see ["5.2.7 Detailed screen with weather-dependent curve" \[p 18\]](#).

Schedule

Indicates if the desired leaving water temperature is according to a schedule. Also see ["5.2.5 Configuration wizard: Main zone" \[p 17\]](#).

| # | Code | Description |
|-------|------|---|
| [3.1] | N/A | <ul style="list-style-type: none"> 0: No 1: Yes |

5.2.7 Detailed screen with weather-dependent curve


When weather-dependent (WD) operation is active the desired leaving water or tank temperature is determined automatically depending on the averaged outdoor temperature. When the outdoor temperature is lower the leaving water or tank temperature will need to be higher as the water pipes will be colder and vice versa.

2-points WD curve

The weather-dependent curve is defined by two setpoints:

- Setpoint (X1, Y2)
- Setpoint (X2, Y1)

Weather-dependent curve:



Possible actions on this screen

| | |
|--|------------------------------|
| | Go through the temperatures. |
| | Change the temperature. |
| | Go to the next temperature. |
| | Confirm changes and proceed. |

| Item | Description |
|---------------|---|
| a | Selected weather dependent zone: <ul style="list-style-type: none"> : Main zone or additional zone heating : Main zone or additional zone cooling : Domestic hot water |
| X1, X2 | Examples of outdoor ambient temperature |
| Y1, Y2 | Examples of desired tank temperature or leaving water temperature. The icon corresponds to the heat emitter for that zone: <ul style="list-style-type: none"> : Underfloor heating : Fan coil unit : Radiator : Domestic hot water tank |

5.2.8 Configuration wizard: Tank

This part only applies to systems with an optional domestic hot water tank installed.

Heat up mode

The domestic hot water can be prepared in 3 different ways. They differ from each other by the way the desired tank temperature is set and how the unit acts upon it.

| # | Code | Description |
|-------|--------|---|
| [5.6] | [6-0D] | Heat up mode <ul style="list-style-type: none"> 0: Reheat only: Only reheat operation is allowed. 1: Schedule + reheat: The domestic hot water tank is heated according to a schedule and between the scheduled heat up cycles, reheat operation is allowed. 2: Schedule only: The domestic hot water tank can ONLY be heated according to a schedule. |

See the operation manual for more details.

**INFORMATION**

Risk of space heating capacity shortage for domestic hot water tank without internal booster heater: In case of frequent domestic hot water operation, frequent and long space heating/cooling interruption will happen when selecting the following:

Tank > Heat up mode > Reheat only.

Comfort setpoint

Only applicable when domestic hot water preparation is Schedule only or Schedule + reheat. When programming the schedule, you can make use of the comfort setpoint as a preset value. When you later want to change the storage setpoint, you only have to do it in one place.

The tank will heat up until the **storage comfort temperature** has been reached. It is the higher desired temperature when a storage comfort action is scheduled.

Additionally, a storage stop can be programmed. This feature puts a stop to tank heating even if the setpoint has NOT been reached. Only program a storage stop when tank heating is absolutely undesirable.

| # | Code | Description |
|-------|--------|-------------------------------------|
| [5.2] | [6-0A] | Comfort setpoint ▪ 30°C~[6-0E]°C |

Eco setpoint

The **storage economic temperature** denotes the lower desired tank temperature. It is the desired temperature when a storage economic action is scheduled (preferably during day).

| # | Code | Description |
|-------|--------|---|
| [5.3] | [6-0B] | Eco setpoint ▪ 30°C~min(50,[6-0E])°C |

Reheat setpoint

Desired reheat tank temperature, used:

- in Schedule + reheat mode, during reheat mode: the guaranteed minimum tank temperature is set by the Reheat setpoint minus the reheat hysteresis. If the tank temperature drops below this value, the tank is heated up.
- during storage comfort, to prioritize the domestic hot water preparation. When the tank temperature rises above this value, domestic hot water preparation and space heating/cooling are executed sequentially.

| # | Code | Description |
|-------|--------|--|
| [5.4] | [6-0C] | Reheat setpoint ▪ 30°C~min(50,[6-0E])°C |

5.3 Settings menu

You can set additional settings using the main menu screen and its submenus. The most important settings are presented here.

5.3.1 Main zone**Thermostat type**

Only applicable in external room thermostat control.

**NOTICE**

If an external room thermostat is used, the external room thermostat will control the room frost protection. However, the room frost protection is only possible if [C.2] Space heating/cooling=0n.

| # | Code | Description |
|-------|--------|---|
| [2.A] | [C-05] | External room thermostat type for the main zone: ▪ 1: 1 contact: The used external room thermostat can only send a thermo ON/OFF condition. There is no separation between heating or cooling demand. ▪ 2: 2 contacts: The used external room thermostat can send a separate heating/cooling thermo ON/OFF condition. |

5.3.2 Additional zone**Thermostat type**

Only applicable in external room thermostat control. For more info about the functionality, see ["5.3.1 Main zone"](#) [p 19].

| # | Code | Description |
|-------|--------|---|
| [3.A] | [C-06] | External room thermostat type for the additional zone: ▪ 1: 1 contact ▪ 2: 2 contacts |

5.3.3 Information**Dealer information**

The installer can fill in his contact number here.

| # | Code | Description |
|-------|------|---|
| [8.3] | N/A | Number that users can call in case of problems. |

5 Configuration

5.4 Menu structure: Overview installer settings

| [9] Installer settings | [9.2] Domestic hot water |
|------------------------------|---------------------------------|
| Configuration wizard | Domestic hot water |
| Domestic hot water | DHW pump |
| Backup heater | DHW pump schedule |
| Booster heater | Solar |
| Emergency | [9.3] Backup heater |
| Balancing | Backup heater type |
| Water pipe freeze prevention | Voltage |
| Benefit kWh power supply | Configuration |
| Power consumption control | Capacity step 1 |
| Energy metering | Additional capacity step 2 |
| Sensors | Equilibrium |
| Bivalent | Equilibrium temperature |
| Alarm output | Operation |
| Auto restart | [9.4] Booster heater |
| Power saving function | Capacity |
| Disable protections | BSH allowance schedule |
| Forced defrost | BSH eco timer |
| Overview field settings | Operation |
| | [9.6] Balancing |
| | Space heating priority |
| | Priority temperature |
| | Offset BSH setpoint |
| | Anti-recycle timer |
| | Minimum running timer |
| | Maximum running timer |
| | Additional timer |
| | [9.8] Benefit kWh power supply |
| | Benefit kWh power supply |
| | Allow heater |
| | Allow pump |
| | [9.9] Power consumption control |
| | Power consumption control |
| | Type |
| | Limit |
| | Limit 1 |
| | Limit 2 |
| | Limit 3 |
| | Limit 4 |
| | Priority heater |
| | [9.A] Energy metering |
| | Electricity meter 1 |
| | Electricity meter 2 |
| | [9.B] Sensors |
| | External sensor |
| | Ext. amb. sensor offset |
| | Averaging time |
| | [9.C] Bivalent |
| | Bivalent |
| | Boiler efficiency |
| | Temperature |
| | Hysteresis |



INFORMATION

Solar kit settings are shown but are NOT applicable for this unit. Settings shall NOT be used or changed.



INFORMATION

Depending on the selected installer settings and unit type, settings will be visible/invisible.

6 Commissioning



NOTICE

ALWAYS operate the unit with thermistors and/or pressure sensors/switches. If NOT, burning of the compressor might be the result.



INFORMATION

Protective functions – "Installer-on-site mode". The software is equipped with protective functions, such as room antifrost. The unit automatically runs these functions when necessary.

During installation or service this behaviour is undesired. Therefore, the protective functions can be disabled:

- **At first power-on:** The protective functions are disabled by default. After 36 h they will be automatically enabled.
- **Afterwards:** An installer can manually disable the protective functions by setting [9.G]: Disable protections=Yes. After his work is done, he can enable the protective functions by setting [9.G]: Disable protections=No.

6.1 Checklist before commissioning

After the installation of the unit, first check the items listed below. Once all checks are fulfilled, the unit must be closed. Power-up the unit after it is closed.

| | |
|--------------------------|---|
| <input type="checkbox"/> | You read the complete installation instructions, as described in the installer reference guide . |
| <input type="checkbox"/> | The indoor unit is properly mounted. |
| <input type="checkbox"/> | The outdoor unit is properly mounted. |
| <input type="checkbox"/> | The following field wiring has been carried out according to this document and the applicable legislation: <ul style="list-style-type: none"> • Between the local supply panel and the outdoor unit • Between indoor unit and outdoor unit • Between the local supply panel and the indoor unit • Between the indoor unit and the valves (if applicable) • Between the indoor unit and the room thermostat (if applicable) • Between the indoor unit and the domestic hot water tank (if applicable) |
| <input type="checkbox"/> | The system is properly earthed and the earth terminals are tightened. |
| <input type="checkbox"/> | The fuses or locally installed protection devices are installed according to this document, and have NOT been bypassed. |
| <input type="checkbox"/> | The power supply voltage matches the voltage on the identification label of the unit. |
| <input type="checkbox"/> | There are NO loose connections or damaged electrical components in the switch box. |
| <input type="checkbox"/> | There are NO damaged components or squeezed pipes on the inside of the indoor and outdoor units. |
| <input type="checkbox"/> | Backup heater circuit breaker F1B (field supply) is turned ON. |
| <input type="checkbox"/> | Only for tanks with built-in booster heater: Booster heater circuit breaker F2B (field supply) is turned ON. |
| <input type="checkbox"/> | There are NO refrigerant leaks . |

| | |
|--------------------------|--|
| <input type="checkbox"/> | The refrigerant pipes (gas and liquid) are thermally insulated. |
| <input type="checkbox"/> | The correct pipe size is installed and the pipes are properly insulated. |
| <input type="checkbox"/> | There is NO water leak inside the indoor unit. |
| <input type="checkbox"/> | The shut-off valves are properly installed and fully open. |
| <input type="checkbox"/> | The stop valves (gas and liquid) on the outdoor unit are fully open. |
| <input type="checkbox"/> | The air purge valve is open (at least 2 turns). |
| <input type="checkbox"/> | The pressure relief valve purges water when opened. Clean water must come out. |
| <input type="checkbox"/> | The minimum water volume is guaranteed in all conditions. See "To check the water volume" in "3.2 Preparing water piping" [p 6] . |
| <input type="checkbox"/> | (if applicable) The domestic hot water tank is filled completely. |

6.2 Checklist during commissioning

| | |
|--------------------------|--|
| <input type="checkbox"/> | The minimum flow rate during backup heater/defrost operation is guaranteed in all conditions. See "To check the water volume and flow rate" in "3.2 Preparing water piping" [p 6] . |
| <input type="checkbox"/> | To perform an air purge . |
| <input type="checkbox"/> | To perform a test run . |
| <input type="checkbox"/> | To perform an actuator test run . |
| <input type="checkbox"/> | Underfloor screed dryout function The underfloor screed dryout function is started (if necessary). |

6.2.1 To check the minimum flow rate

| | | |
|---|---|---|
| 1 | Check the hydraulic configuration to find out which space heating loops can be closed by mechanical, electronic, or other valves. | — |
| 2 | Close all space heating loops that can be closed. | — |
| 3 | Start the pump test run (see "6.2.4 To perform an actuator test run" [p 22]). | — |
| 4 | Read out the flow rate ^(a) and modify the bypass valve setting to reach the minimum required flow rate + 2 l/min. | — |

^(a) During pump test run, the unit can operate below the minimum required flow rate.

| Minimum required flow rate | |
|----------------------------|--|
| 12 l/min | |

6.2.2 To perform an air purge

Conditions: Make sure all operation is disabled. Go to [C]: Operation and turn off Room, Space heating/cooling and Tank operation.

6 Commissioning

| | | |
|---|--|---|
| 1 | Set the user permission level to Installer. See " To change the user permission level " ▶ 14]. | — |
| 2 | Go to [A.3]: Commissioning > Air purge. | |
| 3 | Select OK to confirm. Result: The air purge starts. It stops automatically when air purge cycle is finished. | |
| | To stop the air purge manually: | — |
| 1 | Go to Stop air purge. | |
| 2 | Select OK to confirm. | |

Air purging heat emitters or collectors

We recommend to purge air with the unit's air purge function (see above). However, if you purge air from the heat emitters or collectors, mind the following:



WARNING

Air purging heat emitters or collectors. Before you purge air from heat emitters or collectors, check if or is displayed on the home screen of the user interface.

- If not, you can purge air immediately.
- If yes, make sure that the room where you want to purge air is sufficiently ventilated. **Reason:** Refrigerant might leak into the water circuit, and subsequently into the room when you purge air from the heat emitters or collectors.

6.2.3 To perform an operation test run

Conditions: Make sure all operation is disabled. Go to [C]: Operation and turn off Room, Space heating/cooling and Tank operation.

| | | |
|---|--|---|
| 1 | Set the user permission level to Installer. See " To change the user permission level " ▶ 14]. | — |
| 2 | Go to [A.1]: Commissioning > Operation test run. | |
| 3 | Select a test from the list. Example: Heating. | |
| 4 | Select OK to confirm. Result: The test run starts. It stops automatically when ready (±30 min). | |
| | To stop the test run manually: | — |
| 1 | In the menu, go to Stop test run. | |
| 2 | Select OK to confirm. | |



INFORMATION

If the outdoor temperature is outside the range of operation, the unit may NOT operate or may NOT deliver the required capacity.

To monitor leaving water and tank temperatures

During test run, the correct operation of the unit can be checked by monitoring its leaving water temperature (heating/cooling mode) and tank temperature (domestic hot water mode).

To monitor the temperatures:

| | | |
|---|-------------------------------------|--|
| 1 | In the menu, go to Sensors. | |
| 2 | Select the temperature information. | |

6.2.4 To perform an actuator test run

Conditions: Make sure all operation is disabled. Go to [C]: Operation and turn off Room, Space heating/cooling and Tank operation.

Purpose

Perform an actuator test run to confirm the operation of the different actuators. For example, when you select Pump, a test run of the pump will start.

| | | |
|---|--|---|
| 1 | Set the user permission level to Installer. See " To change the user permission level " ▶ 14]. | — |
| 2 | Go to [A.2]: Commissioning > Actuator test run. | |
| 3 | Select a test from the list. Example: Pump. | |
| 4 | Select OK to confirm. Result: The actuator test run starts. It stops automatically when ready (±30 min). | |
| | To stop the test run manually: | — |
| 1 | In the menu, go to Stop test run. | |
| 2 | Select OK to confirm. | |

Possible actuator test runs

- Booster heater test
- Backup heater 1 test
- Backup heater 2 test
- Pump test



INFORMATION

Make sure that all air is purged before executing the test run. Also avoid disturbances in the water circuit during the test run.

- Shut off valve test
- Diverter valve test (3-way valve for switching between space heating and tank heating)
- Bivalent signal test
- Alarm output test
- C/H signal test
- DHW pump test

6.2.5 To perform an underfloor heating screed dryout

Conditions: Make sure all operation is disabled. Go to [C]: Operation and turn off Room, Space heating/cooling and Tank operation.

| | | |
|---|--|---|
| 1 | Set the user permission level to Installer. See " To change the user permission level " ▶ 14]. | — |
| 2 | Go to [A.4]: Commissioning > UFH screed dryout. | |
| 3 | Set a dryout program: go to Program and use the UFH screed dryout programming screen. | |
| 4 | Select OK to confirm. Result: The underfloor heating screed dryout starts. It stops automatically when done. | |
| | To stop the test run manually: | — |
| 1 | Go to Stop UFH screed dryout. | |
| 2 | Select OK to confirm. | |

**NOTICE**

To perform an underfloor heating screed dryout, room frost protection needs to be disabled ([2-06]=0). By default, it is enabled ([2-06]=1). However, due to the "installer-on-site" mode (see "Commissioning"), room frost protection will be automatically disabled for 36 hours after the first power-on.

If the screed dryout still needs to be performed after the first 36 hours of power-on, manually disable room frost protection by setting [2-06] to "0", and KEEP it disabled until the screed dryout has finished. Ignoring this notice will result in cracking of the screed.

**NOTICE**

For the underfloor heating screed dryout to be able to start, make sure the following settings are met:

- [4-00]=1
- [C-02]=0
- [D-01]=0
- [4-08]=0
- [4-01]≠1


7 Hand-over to the user

Once the test run is finished and the unit operates properly, please make sure the following is clear for the user:

- Fill in the installer setting table (in the operation manual) with the actual settings.
- Make sure that the user has the printed documentation and ask him/her to keep it for future reference. Inform the user that he can find the complete documentation at the URL mentioned earlier in this manual.
- Explain the user how to properly operate the system and what to do in case of problems.
- Show the user what to do for the maintenance of the unit.
- Explain the user about energy saving tips as described in the operation manual.

8 Technical data

8.1 Piping diagram: Indoor unit



- | | |
|--|--|
| A Water side | B1PW Space heating water pressure sensor |
| B Refrigerant side | B2PR Refrigerant pressure sensor |
| C Field installed | R1T Thermistor (heat exchanger – water OUT) |
| a1 Space heating water IN | R2T Thermistor (backup heater – water OUT) |
| a2 Space heating water OUT | R3T Thermistor (liquid refrigerant) |
| b1 Gas refrigerant IN (heating mode; condenser) | R4T Thermistor (heat exchanger – water IN) |
| b2 Liquid refrigerant OUT (heating mode; condenser) | — Screw connection |
| c1 Liquid refrigerant IN (cooling mode; evaporator) | — Flare connection |
| c2 Gas refrigerant OUT (cooling mode; evaporator) | — Quick coupling |
| d Plate heat exchanger | — Brazed connection |
| e Shut-off valve for service | |
| f Magnetic filter/dirt separator | |
| g Safety valve | |
| h Air purge | |
| i Drain valve | |
| j Flow sensor | |
| k Expansion vessel | |
| l Backup heater | |
| m Pump | |

8.2 Wiring diagram: Indoor unit

See the internal wiring diagram supplied with the unit (on the inside of the indoor unit upper front panel). The abbreviations used are listed below.

Notes to go through before starting the unit

| English | Translation |
|---|--|
| Notes to go through before starting the unit | Notes to go through before starting the unit |
| X1M | Main terminal |
| X2M | Field wiring terminal for AC |
| X5M | Field wiring terminal for DC |
| X6M | Backup heater power supply terminal |
| X7M, X8M | Booster heater power supply terminal |
| ----- | Earth wiring |
| ----- | Field supply |
| ① | Several wiring possibilities |
| | Option |
| | Not mounted in switch box |
| | Wiring depending on model |
| | PCB |
| Note 1: Connection point of the power supply for the BUH/BSH should be foreseen outside the unit. | Note 1: Connection point of the power supply for the backup heater/booster heater should be foreseen outside the unit. |
| Backup heater power supply | Backup heater power supply |
| <input type="checkbox"/> 1N~, 230 V | <input type="checkbox"/> 1N~, 230 V |
| <input type="checkbox"/> 3~, 230 V | <input type="checkbox"/> 3~, 230 V |
| <input type="checkbox"/> 3N~, 400 V | <input type="checkbox"/> 3N~, 400 V |
| User installed options | User installed options |
| <input type="checkbox"/> LAN adapter | <input type="checkbox"/> LAN adapter |
| <input type="checkbox"/> Domestic hot water tank | <input type="checkbox"/> Domestic hot water tank |
| <input type="checkbox"/> Remote user interface | <input type="checkbox"/> User interface used as room thermostat |
| <input type="checkbox"/> Ext. indoor thermistor | <input type="checkbox"/> External indoor thermistor |
| <input type="checkbox"/> Ext outdoor thermistor | <input type="checkbox"/> External outdoor thermistor |
| <input type="checkbox"/> Digital I/O PCB | <input type="checkbox"/> Digital I/O PCB |
| <input type="checkbox"/> Demand PCB | <input type="checkbox"/> Demand PCB |
| Main LWT | Main leaving water temperature |
| <input type="checkbox"/> On/OFF thermostat (wired) | <input type="checkbox"/> On/OFF thermostat (wired) |
| <input type="checkbox"/> On/OFF thermostat (wireless) | <input type="checkbox"/> On/OFF thermostat (wireless) |
| <input type="checkbox"/> Ext. thermistor | <input type="checkbox"/> External thermistor |
| <input type="checkbox"/> Heat pump convector | <input type="checkbox"/> Heat pump convector |
| Add LWT | Additional leaving water temperature |
| <input type="checkbox"/> On/OFF thermostat (wired) | <input type="checkbox"/> On/OFF thermostat (wired) |
| <input type="checkbox"/> On/OFF thermostat (wireless) | <input type="checkbox"/> On/OFF thermostat (wireless) |
| <input type="checkbox"/> Ext. thermistor | <input type="checkbox"/> External thermistor |
| <input type="checkbox"/> Heat pump convector | <input type="checkbox"/> Heat pump convector |

Position in switch box

| English | Translation |
|------------------------|------------------------|
| Position in switch box | Position in switch box |

Legend

| | |
|-----|--|
| A1P | Main PCB |
| A2P | * On/OFF thermostat (PC=power circuit) |

| | |
|----------------|---|
| A3P | * Heat pump convector |
| A4P | * Digital I/O PCB |
| A8P | * Demand PCB |
| A9P | Status indicator |
| A10P | MMI (= user interface connected to the indoor unit) – Power supply unit PCB |
| A11P | MMI (= user interface connected to the indoor unit) – Main PCB |
| A12P | MMI display PCB |
| A13P | * LAN adapter |
| A14P | * User interface used as room thermostat – PCB |
| A15P | * Receiver PCB (wireless On/OFF thermostat) |
| B1L | Flow sensor |
| B1PR | Refrigerant pressure sensor |
| B1PW | Water pressure sensor |
| BSK (A3P) | Solar pump station relay |
| CN* (A4P) | * Connector |
| DS1(A8P) | * DIP switch |
| E1H | Backup heater element (1 kW) |
| E2H | Backup heater element (2 kW) |
| E3H | Backup heater element (3 kW) |
| E4H | * Booster heater (3 kW) |
| E*P (A9P) | Indication LED |
| F1B | # Overcurrent fuse backup heater |
| F2B | # Overcurrent fuse booster heater |
| F1T | Thermal fuse backup heater |
| F1U, F2U (A4P) | * Fuse 5 A 250 V for digital I/O PCB |
| FU1 (A1P) | Fuse T 5 A 250 V for PCB |
| FU2 (A10P) | Fuse T 1.6 A 250 V for PCB |
| K1M, K2M | Contactors backup heater |
| K3M | * Contactor booster heater |
| K5M | Safety contactor backup heater |
| K*R (A1P-A4P) | Relay on PCB |
| M1P | Main supply pump |
| M2P | # Domestic hot water pump |
| M2S | # 2-way valve for cooling mode |
| M3S | * 3-way valve for floor heating/domestic hot water |
| P1M | MMI display |
| PC (A15P) | * Power circuit |
| PHC1 (A4P) | * Optocoupler input circuit |
| Q1L | Thermal protector backup heater |
| Q2L | * Thermal protector booster heater |
| Q4L | # Safety thermostat |
| Q*DI | # Earth leakage circuit breaker |
| R1H (A2P) | * Humidity sensor |
| R1T (A1P) | Outlet water heat exchanger thermistor |
| R1T (A2P) | * Ambient sensor On/OFF thermostat |
| R1T (A14P) | * Ambient sensor user interface |
| R2T (A1P) | Outlet backup heater thermistor |
| R2T (A2P) | * External sensor (floor or ambient) |

8 Technical data

| | | |
|------------------|---|---|
| R3T | | Refrigerant liquid side thermistor |
| R4T | | Inlet water thermistor |
| R5T | * | Domestic hot water thermistor |
| R6T | * | External indoor or outdoor ambient thermistor |
| S1S | # | Preferential kWh rate power supply contact |
| S2S | # | Electrical meter pulse input 1 |
| S3S | # | Electrical meter pulse input 2 |
| S6S~S9S | * | Digital power limitation inputs |
| SS1 (A4P) | * | Selector switch |
| SW1~2 (A12P) | | Turn buttons |
| SW3~5 (A12P) | | Push buttons |
| TR1 | | Power supply transformer |
| X6M | # | Backup heater power supply terminal strip |
| X7M, X8M | | Booster heater power supply terminal strip |
| X*, X*A, X*Y, Y* | | Connector |
| X*M | | Terminal strip |

* Optional
Field supply


Translation of text on wiring diagram

| English | Translation |
|---|---|
| (1) Main power connection | (1) Main power connection |
| For preferential kWh rate power supply | For preferential kWh rate power supply |
| Indoor unit supplied from outdoor | Indoor unit supplied from outdoor |
| Normal kWh rate power supply | Normal kWh rate power supply |
| Only for normal power supply (standard) | Only for normal power supply (standard) |
| Only for preferential kWh rate power supply (outdoor) | Only for preferential kWh rate power supply (outdoor) |
| Outdoor unit | Outdoor unit |
| Preferential kWh rate power supply contact: 16 V DC detection (voltage supplied by PCB) | Preferential kWh rate power supply contact: 16 V DC detection (voltage supplied by PCB) |
| SWB | Switch box |
| Use normal kWh rate power supply for indoor unit | Use normal kWh rate power supply for indoor unit |
| (2) Backup heater power supply | (2) Backup heater power supply |
| Only for *** | Only for *** |
| (3) User interface | (3) User interface |
| Only for LAN adapter | Only for the LAN adapter |
| Only for remote user interface | Only for the user interface used as room thermostat |
| (4) Domestic hot water tank | (4) Domestic hot water tank |
| 3 wire type SPST | 3 wire type SPST |
| Booster heater power supply | Booster heater power supply |
| Only for *** | Only for *** |
| SWB | Switch box |
| (5) Ext. thermistor | (5) External thermistor |
| SWB | Switch box |

| English | Translation |
|--|--|
| (6) Field supplied options | (6) Field supplied options |
| 12 V DC pulse detection (voltage supplied by PCB) | 12 V DC pulse detection (voltage supplied by PCB) |
| 230 V AC supplied by PCB | 230 V AC supplied by PCB |
| Continuous | Continuous current |
| DHW pump output | Domestic hot water pump output |
| DHW pump | Domestic hot water pump |
| Electrical meters | Electrical meters |
| For safety thermostat | For safety thermostat |
| Inrush | Inrush current |
| Max. load | Maximum load |
| Normally closed | Normally closed |
| Normally open | Normally open |
| Safety thermostat contact: 16 V DC detection (voltage supplied by PCB) | Safety thermostat contact: 16 V DC detection (voltage supplied by PCB) |
| Shut-off valve | Shut-off valve |
| SWB | Switch box |
| (7) Option PCBs | (7) Option PCBs |
| Alarm output | Alarm output |
| Changeover to ext. heat source | Changeover to external heat source |
| Max. load | Maximum load |
| Min. load | Minimum load |
| Only for demand PCB option | Only for demand PCB option |
| Only for digital I/O PCB option | Only for digital I/O PCB option |
| Options: ext. heat source output, solar pump connection, alarm output | Options: external heat source output, solar pump connection, alarm output |
| Options: On/OFF output | Options: On/OFF output |
| Power limitation digital inputs: 12 V DC / 12 mA detection (voltage supplied by PCB) | Power limitation digital inputs: 12 V DC / 12 mA detection (voltage supplied by PCB) |
| Refer to operation manual | Refer to operation manual |
| Solar input | Solar input |
| Solar pump connection | Solar pump connection |
| Space C/H On/OFF output | Space cooling/heating On/OFF output |
| SWB | Switch box |
| (8) External On/OFF thermostats and heat pump convector | (8) External On/OFF thermostats and heat pump convector |
| Additional LWT zone | Additional leaving water temperature zone |
| Main LWT zone | Main leaving water temperature zone |
| Only for external sensor (floor/ambient) | Only for external sensor (floor or ambient) |
| Only for heat pump convector | Only for heat pump convector |
| Only for wired On/OFF thermostat | Only for wired On/OFF thermostat |
| Only for wireless On/OFF thermostat | Only for wireless On/OFF thermostat |

Electrical connection diagram

For more details, please check the unit wiring.



Notes:

- In case of signal cable: keep minimum distance to power cables >5 cm
- Available heaters depending on model: see combination table

4D111879D


8 Technical data

8.3 Table 1 – Maximum refrigerant charge allowed in a room: indoor unit

| A_{room} (m ²) | Maximum refrigerant charge in a room (m_{max}) (kg) | | | | | | | |
|------------------------------|---|-----------|-----------|-----------|-----------|-----------|-----------|-----------|
| | H=1150 mm | H=1200 mm | H=1300 mm | H=1400 mm | H=1500 mm | H=1600 mm | H=1700 mm | H=1800 mm |
| 1 | 0.25 | 0.26 | 0.29 | 0.31 | 0.33 | 0.36 | 0.38 | 0.40 |
| 2 | 0.51 | 0.53 | 0.58 | 0.62 | 0.67 | 0.71 | 0.76 | 0.81 |
| 3 | 0.76 | 0.79 | 0.86 | 0.93 | 1.00 | 1.07 | 1.14 | 1.21 |
| 4 | 1.01 | 1.06 | 1.15 | 1.24 | 1.34 | 1.43 | 1.52 | 1.61 |
| 5 | 1.27 | 1.32 | 1.44 | 1.55 | 1.67 | 1.78 | 1.90 | 2.01 |
| 6 | 1.52 | 1.59 | 1.73 | 1.87 | 2.00 | 2.14 | 2.28 | 2.42 |
| 7 | 1.66 | 1.74 | 1.89 | 2.04 | 2.19 | 2.34 | 2.49 | 2.65 |
| 8 | 1.78 | 1.86 | 2.02 | 2.18 | 2.34 | 2.50 | 2.67 | 2.83 |
| 9 | 1.89 | 1.97 | 2.14 | 2.31 | 2.49 | 2.66 | 2.83 | 3.00 |
| 10 | 1.99 | 2.08 | 2.26 | 2.44 | 2.62 | 2.80 | 2.98 | 3.16 |

i INFORMATION

- H = Height measured from the bottom of the casing to the floor.
- For intermediate H values (i.e. when H is between two H values from the table), consider the value that corresponds to the lower H value from the table. If H=1450 mm, consider the value that corresponds to "H=1400 mm".
- For intermediate A_{room} values (i.e. when A_{room} is between two A_{room} values from the table), consider the value that corresponds to the lower A_{room} value from the table. If $A_{room}=8.5$ m², consider the value that corresponds to " $A_{room}=8$ m²".



8.4 Table 2 – Minimum floor area: indoor unit

| m_c (kg) | Minimum floor area (m ²) | | | | | | | |
|------------|--------------------------------------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|
| | H=1150 mm | H=1200 mm | H=1300 mm | H=1400 mm | H=1500 mm | H=1600 mm | H=1700 mm | H=1800 mm |
| 1.84 | 8.57 | 7.84 | 6.64 | 5.92 | 5.51 | 5.16 | 4.84 | 4.57 |
| 1.86 | 8.76 | 8.02 | 6.78 | 5.98 | 5.57 | 5.21 | 4.90 | 4.62 |
| 1.88 | 8.95 | 8.19 | 6.93 | 6.05 | 5.63 | 5.27 | 4.95 | 4.67 |
| 1.90 | 9.14 | 8.36 | 7.08 | 6.11 | 5.69 | 5.32 | 5.00 | 4.72 |

i INFORMATION



- H = Height measured from the bottom of the casing to the floor.
- For intermediate H values (i.e. when H is between two H values from the table), consider the value that corresponds to the lower H value from the table. If H=1450 mm, consider the value that corresponds to "H=1400 mm".
- Systems with a total refrigerant charge (m_c) < 1.84 kg (i.e. if the piping length is < 27 m) are NOT subjected to any requirements to the installation room.
- Charges > 1.9 kg are NOT allowed in the unit.



8.5 Table 3 – Minimum venting opening area for natural ventilation: indoor unit

| m_c | m_{max} | $dm=m_c-m_{max}$ (kg) | Minimum venting opening area (cm ²) | | | | | | | |
|-------|-----------|-----------------------|---|-----------|-----------|-----------|-----------|-----------|-----------|-----------|
| | | | H=1150 mm | H=1200 mm | H=1300 mm | H=1400 mm | H=1500 mm | H=1600 mm | H=1700 mm | H=1800 mm |
| 1.9 | 0.1 | 1.80 | 538 | 515 | 495 | 477 | 461 | 446 | 433 | 421 |
| 1.9 | 0.3 | 1.60 | 479 | 458 | 440 | 424 | 410 | 397 | 385 | 374 |
| 1.9 | 0.5 | 1.40 | 419 | 401 | 385 | 371 | 359 | 347 | 337 | 327 |
| 1.9 | 0.7 | 1.20 | 359 | 344 | 330 | 318 | 308 | 298 | 289 | 281 |
| 1.9 | 0.9 | 1.00 | 299 | 287 | 275 | 265 | 256 | 248 | 241 | 234 |
| 1.9 | 1.1 | 0.80 | 240 | 229 | 220 | 212 | 205 | 199 | 193 | 187 |
| 1.9 | 1.3 | 0.60 | 180 | 172 | 165 | 159 | 154 | 149 | 145 | 141 |
| 1.9 | 1.5 | 0.40 | 120 | 115 | 110 | 106 | 103 | 100 | 97 | 94 |
| 1.9 | 1.7 | 0.20 | 63 | 58 | 55 | 53 | 52 | 50 | 49 | 47 |

**INFORMATION**

- H = Height measured from the bottom of the casing to the floor.
- For intermediate H values (i.e. when H is between two H values from the table), consider the value that corresponds to the lower H value from the table. If H=1450 mm, consider the floor area that corresponds to "H=1400 mm".
- For intermediate dm values (i.e. when dm is between two dm values from the table), consider the value that corresponds to the higher dm value from the table. If dm=1.55 kg, consider the value that corresponds to "dm=1.6 kg".





EAC



4P495265-1 D 00000004

ROTEX *a member of **DAIKIN** group*

ROTEX Heating Systems GmbH

Langwiesenstraße 10
D-74363 Göggingen
www.rotex-heating.com

Unsere Partner im Ausland

Our partners abroad • Unsere Partner im Ausland
Nos partenaires à l'étranger • Le nostre sedi all'estero
Neustros representantes en el extranjero
Nasi partnerzy za granicą • Naši partneři v zahraničí

<http://de.rotex-heating.com> > ueber-rotex > international

© ROTEX · Subject to change and correction

4P495265-1D 2019.10