





FTXM71N




The mark shows the piping direction.



Including mounting plate




Terminal block with earth terminal Located inside of the unit



Required space for service and ventilation

Wireless remote control


(ARC466A33)





Indoor unit On/OFF switch

Blade angle

Up/down (automatic)



Left/right (automatic)



Standard location of holes in the wall

Notes

- Total width of unit
- Width of unit against the wall

3D101374B