


The mark (→) shows piping direction

8 0 0



Air flow (Indoor)

Including  
mounting plate

2 1 7


2 1 5

2 9 5

50 Min  
Space for  
maintenance

30 Min  
Space for  
performance

50 Min  
Space for  
maintenance




Front panel  
fixed screws  
(inside)

Flaps  
Signal receiver  
Operation lamp  
Timer lamp  
Intelligent eye lamp  
Indoor unit ON/OFF switch  
Room temp. thermistor (Inside)

Model name plate

Up/down  
(Automatic)


Cooling, dry



**INFRARED REMOTE CONTROL**  
(ARC452A3)

#### BLADE ANGLES


Heating



Fan



Right/left  
(automatic)



**STANDARD LOCATIONS OF WALL HOLES**