


# FTXP20-35L


## Required space for service and ventilation

The → mark shows the piping direction.



Right side

Including mounting plate



Terminal block with earth terminal

Located inside of the unit

Drain hose

Inside diameter: 14mm

Outside diameter: 16mm

Connecting part

The length of the connection hose outside the unit is 470mm.

Liquid pipe

Ø6.4 mm CuT

The length of the pipe outside the unit is 410mm.




Gas pipe

Ø9.5 mm CuT

The length of the pipe outside the unit is 360mm.

Indoor air flow

Minimum space for air passage



Hole for embedded piping

Standard location of holes in the wall

Left side

Bottom side

Front grille fixing screws  
Located inside of the unit

Nameplate  
Located inside of the unit

Flap

Signal receiver

Operation lamp


Timer lamp

Indoor unit On/OFF switch

Room temperature sensor

Located inside of the unit

Signal transmitter



Wireless remote control

Blade angle

Up/down (automatic)

Cooling

Dry

5°

50°

Fan

0°

65°

Heating

15°

65°

Left/right (manual)

45°

45°

(ARC480A11)

3D098287B