





# FTXTM30M




## Required space for service and ventilation



## Wireless remote control


(ARC466A55)

### Signal transmitter




## Blade angle

Up/down (automatic)



Left/right (automatic)



### Notes

1. The → mark shows the piping direction.

## Standard location of holes in the wall

