
BS1Q16A



NOTES

- 1. Electric box can also be fixed on the other side of the unit.
- 2. Be sure to install an inspection door at electric box side.
- 3. Attached pipe is only used in case of connecting with indoor unit capacity index 150 or more and 160 or less.
- Small sound of refrigerant will be made, which may be disturbing.
 Do not install it at the place such as bedroom under roof.