



User and site management



User reference guide

4P533864-1A 2018.08


_	1.	User Administration: Create User
_	2.	User Administration: Edit User
	3.	Building Administration: Create Site
_	4.	Building Administration: Activate Package
	5.	Building Administration: Add Users to a Site
_	6.	Building Administration: Disassociate Users from a Site
	7.	Building Administration: Delete a controller
_	8.	Building Administration: Delete a site
_		

01. User Administration:

Create User



Daikin Cloud Service



Remote and intuitive control

- · Control and monitor your premises whenever you want, wherever you are
- · Intuitive interface to control and set schedules easily saving on running costs and ensuring comfort
- Central control of all devices eliminates any risk of simultaneous heating and cooling in situations where a separate
 heating device is installed

Multi site management

- Key account/technical managers have the convenience of a single, centralised controller for controlling and monitoring all their premises
- · Installers/facility managers can check any errors remotely without having to worry about going to the premises


Energy management

- · Detect sources of energy waste and reduce energy use
- · Benchmark different sites to find heavy energy users and optimise their operation




 Log on to the Daikin Cloud Service website: https://cloud.daikineurope.com






Go to "USER ADMINISTRATION"






Create new user: click "New"






Fill out User information






Select User Role.





Click "Add User"





New user is now created, repeat previous steps to add new users




02. User Administration:

Edit User




User Administration: Edit User



Click on "Edit Symbol" to edit user info



User Administration: Edit User



Edit User info if required and click "Save"



User Administration: User Role Overview

User administration allows the creation of 5 user role types. Most user role types are allowed to create new users of the same or lower level.

User creation according to hierarchy:

- Daikin Administrator: Daikin Administrator, Daikin Affiliate, Installer, Admin and Operator
- Daikin Affiliate: Daikin Affiliate, Installer, Admin and Operator.
- Installer: Installer, Admin and Operator.
- Admin: Admin and Operator.
- Operator: Not allowed to create users.



User Administration: User Creation Steps

CREATOR	ROLE CREATED			
	Daikin Affiliate	Installer	Admin	Operator
Daikin Affiliate	 Full Name E-mail address Password Re-enter Password Select Role Inherits Affiliate from creator 	 Full Name E-mail address Password Re-enter Password Select Role Inherits Affiliate from creator Select installer company 	 Full Name E-mail address Password Re-enter Password Select Role Inherits Affiliate from creator Select installer company Select end customer company 	 Full Name E-mail address Password Re-enter Password Select Role Inherits Affiliate from creator Select installer company Select end customer company

CREATOR	ROLE CREATED				
	Installer	Admin	Operator		
Installer	 Full Name E-mail address Password Re-enter Password Select Role Inherits Affiliate from creator Inherits installer company from creator 	 Full Name E-mail address Password Re-enter Password Select Role Inherits Affiliate from creator Inherits installer company from creator Select end customer company 	 Full Name E-mail address Password Re-enter Password Select Role Inherits Affiliate from creator Inherits installer company from creator Select end customer company 		

User Administration: User Creation Steps


CREATOR	ROLE CREATED		
	Admin	Operator	
Admin	 Full Name E-mail address Password Re-enter Password Select Role Inherits Affiliate from creator Inherits installer company from creator Inherits end customer company from creator 	 Full Name E-mail address Password Re-enter Password Select Role Inherits Affiliate from creator Inherits installer company from creator Inherits end customer company from creator 	



03. Building Administration:


Create Site






Go to "BUILDING ADMINISTRATION"






Click "Create Site"






Fill out Site information






Choose a package from drop down list






Selected Package A: Fill out contact information






Selected Package A + Package B: Fill out contact information for A and B.





Click "Add Site"






New site is registered and LC Number is created





- "Controller LC Number" will be asked during Net commissioning (Commissioning Tool) of the Intelligent Tablet Controller, the ITM (Intelligent Touch Manager) or the LC8.
- Net commissioning can only be finalized when it is executed by the date indicated at "Commissioning window".
 If required, this commissioning window can be extended by clicking the "Extend" button. This will extend the commissioning end date by 3 months.






• The user who created the site will be auto-assigned to this site.



04. Building Administration:


Activate Package






Go to "BUILDING ADMINISTRATION"






Click "Edit" icon of the site where you want to activate a package






Click on the vertical ellipsis






Click on "Confirm payment"






- Enter an expiration date
- Click "Confirm"





Status changes to "Paid"






Active packages are indicated with a green icon



05. Building Administration:


Add users to a site






Go to "BUILDING ADMINISTRATION"

4P533864-1A – 2018.08




Click "Edit Symbol" of the site where you want to add a user






New user can be assigned by clicking "Add user to site"






Select user from the drop down list and click "Save"





New user is now assigned.






The site is now visible for the new user in:

06. Building Administration:

Disassociate users from a site




Building Administration: Disassociate Users from a Site



- Go to "BUILDING ADMINISTRATION"
- 44 Select "SITE LIST"




Building Administration: Disassociate Users from a Site



• Click "Edit" icon of the site where you want to disassociate a user



Building Administration: Disassociate Users from a Site



Click "Delete" icon to disassociate the user from the selected site




07. Building Administration:

Delete a controller




Building Administration: Delete a Controller



Go to "BUILDING ADMINISTRATION"




Building Administration: Delete a Controller



Click "Edit" icon of the site where you want to delete a controller



Building Administration: Delete a Controller



Click "Delete" icon of the controller you want to delete




08. Building Administration:

Delete a site




Building Administration: Delete a Site



- Go to "BUILDING ADMINISTRATION"
- 52 Select "SITE LIST"



Building Administration: Delete a Site



Click "Delete" icon of the site you want to remove



Thank you